# Triggers.ToggleMappingEnable

Void Triggers.ToggleMappingEnable(Int32 mappingId)

ΑΡΙ	http://api.avolites.com/10.1/Triggers.ToggleMappingEnable.html
description	Toggles whether a mapping is enabled.
namespace	Triggers
parameter	mappingId ( Int32 ) : The ID of the trigger mapping to toggle
return value	Void

## This is version-dependent

In Titan v10, the mappingId is independent from the titanId and starts at 0:

- mappingId 0 refers to the factory mapping DJ Tap
- mappingId 1 refers to the factory mapping MIDI Show Control
- mappingId 2 refers to the first user-defined macro
- mappingId 3 refers to the second user-defined macro
- user-defined macros are numbered in the order of their creation. However they are displayed in an alphanumerical order regardless which one was created first.

**From Titan v11 on** the mappingId is part of the titanId scope which are created internally and cannot be changed nor made visible easily.

I found that in a **new show in v11** the factory defined mappings have the titanIds 1815 and 1816, and user-defined macros start with 1817. but this may change as soon as anything else is programmed, and is of limited use.

In a **new show in v12** the factory mappings have titanIds 1817 and 1818 and the user-defined macros start thereafter. However v12 has a function to make use of the mapping's user number: Triggers.ToggleMappingEnabledByHandle(). The user numbers cannot be edited or displayed but are assigned in a similar fashion like the mappingIds in v10 (see above): the factory mappings have Ids 1 and 2, and the user defined mappings start from Id 3.

### Example in

Trigger - Toggle Trigger Mappings v10/v11:

<step>Triggers.ToggleMappingEnable(2)</step>

### Also used in

- Trigger Toggle Trigger Mappings v10/v11
- Function list

Last update: 2020/01/26 macros:function:triggers.togglemappingenable https://avosupport.de/wiki/macros/function/triggers.togglemappingenable?rev=1580034079 10:21

Triggers.ToggleMappingEnabledByHandle()

#### Remarks

From: https://avosupport.de/wiki/ - **AVOSUPPORT** 

Permanent link: https://avosupport.de/wiki/macros/function/triggers.togglemappingenable?rev=1580034079

Last update: 2020/01/26 10:21

