

Ai Modules

Latch

section	Controller
short description	stores the input value when triggered and outputs it.
licence level	Bondi
ports	In [numeric/control] Trigger [numeric/control] Out [numeric/control]
skins	./.
hidden parameters	Trigger Mode [dropdown list], options Edge Up , Positive

used in example

- [Midi Layer Select](#)
- [Modules](#)

Manual

When triggered, latches and stores the input value, always outputting the most recently latched value



From:

<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:

<https://avosupport.de/wiki/ai/modules/controller/latch?rev=1539585182>

Last update: **2018/10/15 06:33**

