

Ai Modules

TCP Client Module

This module is rather new, and not in the manual.

| | |
|--------------------------|---|
| section | Network |
| short description | send messages as TCP |
| licence level | ??? |
| ports | Reset Trigger [control/numeric] |
| | Message Received Out [string] |
| | Set Message to Send [string] |
| | Send Trigger [control/numeric] |
| parameter | Set IP1...Set IP4 [text/numeric] - nibbles of the target IP address |
| | Port [text/numeric] - the target port |
| | Reset [push button] - reset the module |
| | Status [text] - the status of the connection |
| | Message In [text] |
| | Message to Send [text] |
| skins | Send [push button] |
| | ./. |

used in example

- [Artnet Video Switch](#)

Manual

this module is not yet in the manual



From:
<https://www.avosupport.de/wiki/> - AVOSUPPORT

Permanent link:
https://www.avosupport.de/wiki/ai/modules/network/tcp_client

Last update: 2018/10/17 15:20

