Modules

As stated in the Introduction modules are the smallest parts used in the Ai node-based engine. They are provided by the Ai system. A full list of the available modules is published in the manual which is installed with the software in Distrib\Help\Ai_Man_v8.chm and in the V9 User Manual available at the Avolites Download site.

The modules used in the examples in this wiki are explained here as well so that you can easily link between modules and their use in real-life patches.

Currently these modules are discussed in this wiki:

Subnamespaces:

3

- 3D Morph Model

A

- AiMediaTileTrigger
- ArtNet Input Large
- Artnet Input Small
- ArtNet Server
- Auto Select

B

- BlendMode

C

- Camera (Controller)
- Camera (GL)
- Clear
- Const Diff
- Constant
- ConstantWithText
- controller
- Convert To String
- CSV File Reader

E

- Ethernet Command

F

- file_io
- Filename As String

F cont.

- Formula

G

- generator
- gl

I

- import

J

- Javascript

L

- Latch
- Light

M

- math
- Monitor

N

- network
- Notepad
- Null Render

P

- patch
- Patch IO

R

- Rectangle
- Render Merge
- Render To Texture

S

- Scale

S cont.

- scripting
- String Combine
- String Length
- String Texture
- String To Number
- Sub String

T

- TCP Client Module
- TexScale

- text
- Text (Generator)
- TexTranslate
- Texture
- Translate

U

- ui

V

- Vector
- Vector Join
- Vector Math

W

- Window

From:
https://avosupport.de/wiki/ - **AVOSUPPORT**

Permanent link:
https://avosupport.de/wiki/ai/modules?rev=1539582599

Last update: **2018/10/15 05:50**