

Function

Handles.CopyDestination

```
Void Handles.CopyDestination(String group, Int32 index)
```

API	http://api.avolites.com/10.1/Handles.CopyDestination.html
description	Second stage of a copy or move operation. Set destination start point.
namespace	Handles
parameter	group (String) : destination handle group. See location for the available groups. index (Int32) : index of the new handle within this group.
return value	Void

Example in

Move (Copy) Handle:

```
<step pause="0.01">Handles.CopyDestination("Playbacks", 7)</step>
```

Also used in

- [Macro - Copy Macro by Macroid](#)
- [Create Dummy Palettes](#)
- [Move \(Copy\) Handle](#)
- [PaletteChaseChanger \(V3\)](#)
- [Programmer - Park/Restore/Swop](#)
- [Function list](#)

Remarks

From:
<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
<https://avosupport.de/wiki/macros/function/handles.copydestination?rev=1519473325>

Last update: **2018/02/24 11:55**

