

Function

# Handles.CopyDestination

Void Handles.CopyDestination(String group, Int32 index)

<b>API</b>	<a href="http://api.avolites.com/10.1/Handles.CopyDestination.html">http://api.avolites.com/10.1/Handles.CopyDestination.html</a>
<b>description</b>	Second stage of a copy or move operation. Set destination start point.
<b>namespace</b>	Handles
<b>parameter</b>	group ( <a href="#">String</a> ) : destination handle group. See <a href="#">location</a> for the available groups. index ( <a href="#">Int32</a> ) : index of the new handle within this group.
<b>return value</b>	<a href="#">Void</a>

### Example in

Move (Copy) Handle:

```
<step pause="0.01">Handles.CopyDestination("Playbacks", 7)</step>
```

### Also used in

- [Macro - Copy Macro by Macroid](#)
- [Create Dummy Palettes](#)
- [Move \(Copy\) Handle](#)
- [PaletteChaseChanger \(V3\)](#)
- [Programmer - Park/Restore/Swop](#)
- [Function list](#)

### Remarks

From:  
<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:  
<https://avosupport.de/wiki/macros/function/handles.copydestination?rev=1519473325>

Last update: **2018/02/24 11:55**

