Function

Handles.MobileWingAExecutor.ChangePage

ASSUMPTION

> This function is not documented and simply deducted from other factory macros, and found working. Hence, this entire documentation is assumed.

```
Void Handles.MobileWingAExecutors.ChangePage(int32 index)
```

API	no
description	toggles the Executors on the first connected Titan Mobile Faderwing to a specific page
Namespaces	handles.mobilewingaexecutors
parameter	Int32 index – the index of the page to change to
return value	(Void)

Example in

Pages - Change All Playback Pages:

```
  <macro id="Avolites.Macros.ChangeToPage1" name="Playbacks Page 1">
    <description>Changes the Mobile Wing playbacks page to page
1.</description>
    <sequence>
       <step>Handles.MobileWingAExecutor.ChangePage(0)</step>
    </sequence>
  </macro>
```

Also used in

- Pages - Change All Playback Pages
- Function list

Remarks

From:
https://avosupport.de/wiki/ - **AVOSUPPORT**

Permanent link:
https://avosupport.de/wiki/macros/function/handles.mobilewingaexecutor.changepage?rev=1541005179

Last update: **2018/10/31 16:59**