

Function

Handles.SapphireWingBTop.ChangePage

ASSUMPTION

This function is not documented and simply deducted from other factory macros, and found working. Hence, this entire documentation is assumed.

```
Void Handles.SapphireWingATop.ChangePage(int32 index)
```

API	no
description	toggles the top Playbacks on the second connected Sapphire Touch Faderwing to a specific page
Namespaces	Handles.SapphireWingBTop
parameter	Int32 index – the index of the page to change to
return value	(Void)

Example in

Pages - Change All Playback Pages:

```
<macro id="Avolites.Macros.ChangeToPage1" name="Playbacks Page 1">
    <description>Changes the Sapphire Wing playbacks page to page
1.</description>
    <sequence>
        <step>Handles.SapphireWingBTop.ChangePage(0)</step>
    </sequence>
</macro>
```

Also used in

- Pages - Change All Playback Pages
- Function list

Remarks

From:
<https://avosupport.de/wiki/> - AVOSUPPORT



Permanent link:
<https://avosupport.de/wiki/macros/function/handles.sapphirewingbtop.changepage>

Last update: **2017/11/22 10:01**