

Function

Masters.SetMaster

```
Void Masters.SetMaster(Handle handle, Single value)
```

API	http://api.avolites.com/11.0/Masters.SetMaster.html
description	Sets the level of the master on the given handle.
namespace	Masters
parameter	handle (Handle) : The handle to set the level for. value (Single) : The new value of the master.
return value	Void

The best way to refer to a master is its [titanId](#)

Example in

[Masters - Rate Master Functions](#):

```
<step>Masters.SetMaster(1613, 1)</step>
```

Also used in

- [Masters - Rate Master Functions](#)
- [Set Grandmaster](#)
- [Masters - Size Master Functions](#)

Remarks

From:
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
<https://www.avosupport.de/wiki/macros/function/masters.setmaster>

Last update: **2019/05/03 16:18**

