

Function

Masters.SetSpeed

```
Void Masters.SetSpeed(Handle handle, Single value)
```

API	http://api.avolites.com/10.1/Masters.SetSpeed.html
description	Sets the speed of a speed master from the menu.
namespace	Masters
parameter	handle (Handle) : the handle of the master. See titanId for special IDs value (Single) : numerical value to set the master to
return value	Void

Example in

[Masters - BPM Master - Set Speed](#):

```
<step>Masters.SetSpeed(1607, 85.000)</step>
```

another example in <http://forum.avolites.com/viewtopic.php?f=20&t=5731>:

```
Masters.SetSpeed("Location=Playbacks,1,10", float:120)
```

Also used in

- [Masters - BPM Master - Set Speed](#)
- [Function list](#)

Remarks

This sets the value the fader is currently set to (in Playback Options). If the fader is currently set to BPM then the bpm rate is set. If the master is currently set to 'Multiplier on Fader' then the multiplier is set.

From:
<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
<https://avosupport.de/wiki/macros/function/masters.setspeed?rev=1536427013>

Last update: **2018/09/08 17:16**

