

Function

# Masters.TapTempo

```
Void Masters.TapTempo(Handle handle, DateTime panelTimeStamp)
```

<b>API</b>	<a href="http://api.avolites.com/10.1/Masters.TapTempo.html">http://api.avolites.com/10.1/Masters.TapTempo.html</a>
<b>description</b>	Sets the speed of the master from the tap speed of a key.
<b>namespace</b>	Masters
<b>parameter</b>	handle ( <a href="#">Handle</a> ) : the master handle to apply the tap on panelTimeStamp ( <a href="#">Timestamp</a> ) : The panel time stamp. The software then calculates the beat based on the timestamps of the various taps.
<b>return value</b>	<a href="#">Void</a>

## Example in

[Masters - BPM Master \(snippet\)](#):

```
<step>Masters.TapTempo(1607, Math.GetCurrentTimeStamp())</step>
```

## Also used in

- [Masters - BPM Master \(snippet\)](#)
- [Masters - BPM - Tap](#)
- [Masters - BPM Master - Set Speed](#)
- [Function list](#)
- [Math.GetCurrentTimeStamp](#)
- [Handle](#)

## Remarks

From:  
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:  
<https://www.avosupport.de/wiki/macros/function/masters.taptempo>

Last update: **2018/06/19 15:41**

