

Function

Masters.TapTempo

```
Void Masters.TapTempo(Handle handle, DateTime panelTimeStamp)
```

API	http://api.avolites.com/10.1/Masters.TapTempo.html
description	Sets the speed of the master from the tap speed of a key.
namespace	Masters
parameter	handle (handle) : the master handle to apply the tap on panelTimeStamp (timestamp) : The panel time stamp. The software then calculates the beat based on the timestamps of the various taps.
return value	Void

Example in

[Masters - BPM Master \(snippet\)](#):

```
<step>Masters.TapTempo(1607, Math.GetCurrentTimeStamp())</step>
```

Also used in

- [Masters - BPM Master \(snippet\)](#)
- [Masters - BPM - Tap](#)
- [Masters - BPM Master - Set Speed](#)
- [Function list](#)
- [Math.GetCurrentTimeStamp](#)
- [Handle](#)

Remarks

From:

<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:

<https://avosupport.de/wiki/macros/function/masters.taptempo?rev=1517137954>

Last update: **2018/01/28 11:12**

