

# SetCurrentMacroFromUserNumber

```
Void UserMacros.SetCurrentMacroFromUserNumber(Int32 userNumber)
```

<b>API</b>	<a href="http://api.avolites.com/10.1/UserMacros.SetCurrentMacroFromUserNumber.html">http://api.avolites.com/10.1/UserMacros.SetCurrentMacroFromUserNumber.html</a>
<b>description</b>	Sets the current macro information from the user number, i.e. flags the macro with this user number as 'current'.
<b>Namespaces</b>	UserMacros
<b>parameter</b>	userNumber ( Int32 ) : The user number of the macro to set the current information to.
<b>return value</b>	(Void)

## Example in

exportmacro:

```
<step>UserMacros.SetCurrentMacroFromUserNumber(1)</step>
```

## Also used in

- [Macro - Export Macro](#)
- [Function list](#)

## Remarks

From:

<https://avosupport.de/wiki/> - AVOSUPPORT

Permanent link:

<https://avosupport.de/wiki/macros/function/setcurrentmacrofromusernumber?rev=1509294873>

Last update: **2017/10/29 16:34**

