

Function

System.LockConsole

```
Void System.LockConsole(String lockCode)
```

API	http://api.avolites.com/10.1/System.LockConsole.html
description	Puts the console in the locked state and sets the current password.
namespace	System
parameter	lockCode(String) : The code required to unlock the console.
return value	Void

Example in

[System - Lock Console](#):

```
System.LockConsole("1009")
```

Also used in

- [System - Lock Console](#)
- [Function list](#)

Remarks

From:
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
<https://www.avosupport.de/wiki/macros/function/system.lockconsole>

Last update: **2018/02/17 20:26**

