

Function

Timecode.TimecodeOne.SetStartTime

Nowadays there are four timecodes available in Titan, and the same functions are available for [Timecode.TimecodeTwo](#), [Timecode.TimecodeThree](#) and [Timecode.TimecodeFour](#).

```
Void Timecode.TimecodeOne.SetStartTime(TimecodeTime time)
```

| | |
|---------------------|---|
| API | https://api.avolites.com/12.0/Timecode.TimecodeOne.SetStartTime.html |
| description | Sets the start time for a timer in Titan. |
| namespace | Timecode.TimecodeOne |
| parameter | time (TimecodeTime) : the time to be set as start time |
| return value | Void |

Example in

[Timecode - Set Start Time](#):

```
<step>Timecode.TimecodeFour.SetStartTime(Timecode.MakeTimecodeTime(11, 00, 00, 00, false, 100))</step>
```

Sets the timecode 4 start time to a specific value which has previously been written into a timecodeime object using `Timecode.MakeTimecodeTime(11, 00, 00, 00, false, 100)`

Also used in

- [Timecode - Set starttime to livetime and toggle source](#)
- [Timecode - Set Start Time](#)
- [Timecode - Set Start Time from Palette Fade](#)
- [Timecode - Winamp Tracks](#)
- [Timecode.MakeTimecodeTime](#)

Remarks

From:
<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
<https://avosupport.de/wiki/macros/function/timecode.timecodeone.setstarttime>

Last update: **2020/03/29 12:46**

