

Function

# Timecode.TimecodeOne.SetStartTime

Nowadays there are four timecodes available in Titan, and the same functions are available for [Timecode.TimecodeTwo](#), [Timecode.TimecodeThree](#) and [Timecode.TimecodeFour](#).

```
Void Timecode.TimecodeOne.SetStartTime(TimecodeTime time)
```

<b>API</b>	<a href="https://api.avolites.com/12.0/Timecode.TimecodeOne.SetStartTime.html">https://api.avolites.com/12.0/Timecode.TimecodeOne.SetStartTime.html</a>
<b>description</b>	Sets the start time for a timer in Titan.
<b>namespace</b>	<a href="#">Timecode.TimecodeOne</a>
<b>parameter</b>	time ( <a href="#">TimecodeTime</a> ) : the time to be set as start time
<b>return value</b>	<a href="#">Void</a>

## Example in

[Timecode - Set Start Time:](#)

```
<step>Timecode.TimecodeFour.SetStartTime(Timecode.MakeTimecodeTime(11, 00, 00, 00, false, 100))</step>
```

Sets the timecode 4 start time to a specific value which has previously been written into a timecodeime object using `Timecode.MakeTimecodeTime(11, 00, 00, 00, false, 100)`

## Also used in

- [Timecode - Set starttime to livetime and toggle source](#)
- [Timecode - Set Start Time](#)
- [Timecode - Set Start Time from Palette Fade](#)
- [Timecode - Winamp Tracks](#)
- [Timecode.MakeTimecodeTime](#)

## Remarks

From:  
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:  
<https://www.avosupport.de/wiki/macros/function/timecode.timecodeone.setstarttime>

Last update: **2020/03/29 12:46**

