Function

Timecode.TimecodeOne.SetStartTime

Nowadays there are four timecodes available in Titan, and the same functions are available for Timecode.TimecodeTwo, Timecode.TimecodeThree and Timecode.TimecodeFour.

```
Void Timecode.TimecodeOne.SetStartTime(TimecodeTime time)
```

API	https://api.avolites.com/12.0/Timecode.TimecodeOne.SetStartTime.html
description	Sets the start time for a timer in Titan.
namespace	Timecode.TimecodeOne
parameter	time (TimecodeTime) : the time to be set as start time
return value	Void

Example in

Timecode - Set Start Time:

```
<step>Timecode.TimecodeFour.SetStartTime(Timecode.MakeTimecodeTime(11, 00, 00, 00, false, 100))</step>
```

Sets the timecode 4 start time to a specific value which has previously been written into a timecodeime object using `Timecode.MakeTimecodeTime(11, 00, 00, 00, false, 100)`

Also used in

- Timecode - Set starttime to livetime and toggle source
- Timecode - Set Start Time
- Timecode - Set Start Time from Palette Fade
- Timecode - Winamp Tracks
- Timecode.MakeTimecodeTime

Remarks

From:
https://avosupport.de/wiki/ - **AVOSUPPORT**

Permanent link:
https://avosupport.de/wiki/macros/function/timecode.timecodeone.setstarttime?rev=1585485981

Last update: **2020/03/29 12:46**