Function

Triggers.AddMidiTrigger

```
Void Triggers.AddMidiTrigger(Int32 mappingId, TriggerTargetData targetData,
Int32 channel, PanelMidiCommands panelCommand,
                             Int32 value, Int32 min, Int32 max, Int32
threshold, Boolean useLevelMatching)
```

API	http://api.avolites.com/11.0/Triggers.AddMidiTrigger.html
description	Adds a midi trigger and sets all its details.
namespace	Triggers
parameter	mappingId (Int32) : The id of the mapping to add the trigger to.
	targetData (TriggerTargetData) : The target data.
	parameter2 (type) : description of parameter2
	parameter2 (type) : description of parameter2
	parameter2 (type) : description of parameter2
	parameter2 (type) : description of parameter2
	parameter2 (type) : description of parameter2
return value	Void

Example in

example:

```

```

Also used in

- Trigger - Add MIDi trigger

Remarks

From:
https://avosupport.de/wiki/ - **AVOSUPPORT**

Permanent link:
https://avosupport.de/wiki/macros/function/triggers.addmiditrigger?rev=1537093145

Last update: **2018/09/16 10:19**