Function

Triggers.ToggleMappingEnable

```
Void Triggers.ToggleMappingEnable(Int32 mappingId)
```

API	http://api.avolites.com/10.1/Triggers.ToggleMappingEnable.html
description	Toggles whether a mapping is enabled.
namespace	Triggers
parameter	mappingId (Int32) : The ID of the trigger mapping to toggle
	As the first two mappings are predefined and cannot be altered, the first user mapping is ID=2.
return value	Void

Example in

Trigger - Toggle Trigger Mappings v10/v11:

```
<step>Triggers.ToggleMappingEnable(2)</step>
```

Also used in

- Trigger - Toggle Trigger Mappings v10/v11
- Function list
- Triggers.ToggleMappingEnabledByHandle()

Remarks

From:
https://avosupport.de/wiki/ - **AVOSUPPORT**

Permanent link:
https://avosupport.de/wiki/macros/function/triggers.togglemappingenable?rev=1516349976

Last update: **2018/01/19 08:19**