

Function

Visualiser.Capture.UpdatePosition

```
Void Visualiser.Capture.UpdatePosition
  (CaptureCameraPositionsContainer postionsContainer,
   AvailableCameras selectedCamera,
   CaptureCameraPosition sourcePosition)
```

API	http://api.avolites.com/11.0/Visualiser.Capture.UpdatePosition.html
description	Updates the position of a camera.
namespace	Visualiser.Capture
parameter	postionsContainer (CaptureCameraPositionsContainer) : Windows.Visualiser.Capture.CameraPositions
	selectedCamera (AvailableCameras) : Windows.Visualiser.Capture.SelectedCamera
	sourcePosition (CaptureCameraPosition) : see example below
return value	Void

Currently it is not possible to create an arbitrary position by means of a macro. It is only possible to reference the predefined positions, see below.

Example in

[Capture - Camera](#):

```
<step>Visualiser.Capture.UpdatePosition
  (Windows.Visualiser.Capture.CameraPositions,
   Windows.Visualiser.Capture.SelectedCamera,
   CaptureCameraPositions.GetPresetPosition
    (Math.ToEnum("Avolites.Titan.Controllers.Console",
 "Avolites.Titan.Controllers.Console.CaptureVisualiser.CaptureCameraPresetPos
 ition",
   "TopView")))</step>
```

Also used in

- [Capture - Camera](#)

Remarks

Last update: 2019/05/05 11:39 macros:function:visualiser.capture.updateposition <https://www.avosupport.de/wiki/macros/function/visualiser.capture.updateposition>

From:
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
<https://www.avosupport.de/wiki/macros/function/visualiser.capture.updateposition>

Last update: **2019/05/05 11:39**

