

Function

Windows.Scrolling.Vertical.Scroll

```
Void Windows.Scrolling.Vertical.Scroll(Int32 value)
```

API	http://api.avolites.com/11.0/Windows.Scrolling.Vertical.Scroll.html
description	Scrolls the currently selected window up/down by [value] pixel.
namespace	Windows.Scrolling.Vertical
parameter	value (Int32) : the amount to scroll by negative values scroll up, positive values scroll down as a rule of thumb, on a fullHD display with normal button size and number, each button row is approx. 50 px. high. Thus, Scroll(1000) would scroll approx. 20 rows down.
return value	Void

Example in

Create Workspaces:

```
<step>Windows.Scrolling.Vertical.Scroll(-100000)</step>
```

Also used in

- [Attribute Wheels And Palette Windows](#)
- [Create Workspaces](#)
- [Function list](#)

Remarks

From:
<https://www.avosupport.de/wiki/> - AVOSUPPORT

Permanent link:
<https://www.avosupport.de/wiki/macros/function/windows.scrolling.vertical.scroll>

Last update: **2018/08/26 11:07**

