Types/Object/Handle/Location

RollerA

This is the main playback area. Due to different designs, there are slight differences on the various consoles:

- On the Pearl Expert, RollerA refers to the left-hand roller. It sports 10 handles on 30 pages in total (10 facets, 3 button pages)
- On the Sapphire Touch, this is the bottom fader area. It sports 15 handles on 60 pages. Note that, as this roller has 10 faders on all other consoles, items on places 11~15 might be available in the show library only.
- On all other consoles, RollerA refers to the main playback area as well: 10 faders on 60 pages. However, only odd pages are refering to roller A while even pages are refering to roller B.

Roller A on a Pearl Expert

Bottom Playbacks on the Sapphire Touch

Playbacks on the Titan Mobile (likewise on Quartz and Titan One) - odd pages only

Playbacks on the Tiger Touch - odd pages only

Main Playbacks on the Arena - odd pages only

From:
https://avosupport.de/wiki/ - **AVOSUPPORT**

Permanent link:
https://avosupport.de/wiki/macros/identifier/location/rollera?rev=1529423582

Last update: **2018/06/19 15:53**