

Identifier/Location


# RollerA

This is the main playback area. Due to different designs, there are slight differences on the various consoles:


- On the Pearl Expert, RollerA refers to the left-hand roller. It sports 10 handles on 30 pages in total (10 facets, 3 button pages)
- On the Sapphire Touch, this is the bottom fader area. It sports 15 handles on 60 pages. Note that, as this roller has 10 faders on all other consoles, items on places 11~15 might be available in the show library only.
- On all other consoles, RollerA refers to the main playback area as well: 10 faders on 60 pages. However, only odd pages are referring to roller A while even pages are referring to roller B.

**As of version 11, the use of RollerA as location is discouraged. Better use Location:Playbacks instead.**


Roller A on a Pearl Expert




Bottom Playbacks on the Sapphire Touch




Playbacks on the Titan Mobile (likewise on Quartz and Titan One) - odd pages only



Playbacks on the Tiger Touch - odd pages only



Main Playbacks on the Arena - odd pages only



From:  
<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:  
<https://avosupport.de/wiki/macros/identifier/location/rollera?rev=1529423881>

Last update: **2018/06/19 15:58**

