

Titan Property

Patch.CurrentDmxAssignment

API	./.
description	the DMX address to be used in the next patch process
Namespaces	Patch
type	DmxAssignment see example, seems to be something like {line}.{channel}

This property is inherently set by Patch.SetCurrentDmxAssignment.

example

```
<step>Patch.SetCurrentDmxAssignment(42.1)</step>
```

(Explanation)

used in

- Patch - Repatch Selected Fixtures
- Patch.SetCurrentDmxAssignment
- DmxAssignment

From:

<https://avosupport.de/wiki/> - AVOSUPPORT

Permanent link:

<https://avosupport.de/wiki/macros/property/patch.currentdmxassignment?rev=1745920535>

Last update: 2025/04/29 09:55

