

Titan Property

Playbacks.MasterReleaseTime

API	http://api.avolites.com/10.1/Playbacks.MasterReleaseTime.html
description	The default time to fade when releasing a playback.
Namespaces	Playbacks
type	AcwTimeSpan

See [Release - Set Master Release Time](#) for some more info on casting this value.

example

```
Playbacks.ReleasePlayback(userNumber:2, Playbacks.MasterReleaseTime, true)
```

Releases a given playback in the global release time. (It is believed that this example is redundant, as the 3rd parameter makes it fade in the maaster release time anyway).

used in

- [Playback - Fire/Release Playbacks from Usernumber](#)
- [Release - Master Release Time](#)
- [Release playback whether it exists or not \(snippet only\)](#)
- [Release - Set Master Release Time](#)
- [Playbacks.ReleasePlayback](#)
- [Properties list](#)
- [AcwTimeSpan](#)

From: <https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link: <https://avosupport.de/wiki/macros/property/playbacks.masterreleasetime?rev=1521815697>

Last update: **2018/03/23 14:34**

