

Titan Property

Programmer.CurrentProgrammerIds

| | |
|--------------------|---|
| API | https://api.avolites.com/12.0/Programmer.CurrentProgrammerIds.html |
| description | Gets or sets the current programmer Playback and Cue ID value pair. |
| Namespaces | Programmer |
| type | Object |

example

```
<step  
pause="0.001">Programmer.RefireProgrammer(Programmer.CurrentProgrammerIds)</  
step>
```

Here, `Programmer.CurrentProgrammerIds` is passed to `Programmer.RefireProgrammer` in order to restart the shapes currently in the programmer.

used in

- [Shapes - Reverse, Offset, Restart](#)
- [AcwProgrammerIdPair](#)

From:
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
<https://www.avosupport.de/wiki/macros/property/programmer.currentprogrammerids>

Last update: **2020/03/29 09:16**

