Titan Property

Programmer.CurrentProgrammerIds

API	https://api.avolites.com/12.0/Programmer.CurrentProgrammerIds.html
description	Gets or sets the current programmer Playback and Cue ID value pair.
Namespaces	Programmer
type	Object

example

```
  <step
pause="0.001">Programmer.RefireProgrammer(Programmer.CurrentProgrammerIds)</
step>
```

Here, `Programmer.CurrentProgrammerIds` is passed to `Programmer.RefireProgrammer` in order to restart the shapes currently in the programmer.

used in

- Shapes - Reverse, Offset, Restart
- AcwProgrammerIdPair

From:
https://avosupport.de/wiki/ - **AVOSUPPORT**

Permanent link:
https://avosupport.de/wiki/macros/property/programmer.currentprogrammerids?rev=1585473381

Last update: **2020/03/29 09:16**