

Web API request

# Masters/ClearFlash

Clears the flash on a master and resets to the fader level.

|                  |  |
|------------------|--|
| <b>API</b>       | <a href="https://api.avolites.com/12.0/Masters.ClearFlash.html">https://api.avolites.com/12.0/Masters.ClearFlash.html</a>  |
| <b>namespace</b> | Masters  |
| <b>usage</b>     | <code>http://[ip]:4430/titan/script/2/Masters/ClearFlash?handle={handle}</code>  |
| <b>example</b>   | <a href="http://localhost:4430/titan/script/2/Masters/ClearFlash?handle_titanId=1605">http://localhost:4430/titan/script/2/Masters/ClearFlash?handle_titanId=1605</a> (link opens in new tab)      |
| <b>action</b>    | un-flashes the grand master and resets it to the previous level  |
| <b>parameter</b> | <b>Handle</b> - the master to be unflashed   |
| <b>returns</b>   | nothing if successful<br>error message if request failed   |
| <b>remarks</b>   | Using a usernumber to identify the master will fail as masters don't have one. Either assign the master to a handle and use its location or use the reserved Titan ID, see <a href="#">titanId</a> |

## Used In

- [MIDI To Web](#)
- [Web-API requests](#)
- [Masters/DeadBlackOut](#)
- [Masters/Flash](#)

From:  
<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:  
[https://avosupport.de/wiki/webapi/requests/masters\\_clearflash](https://avosupport.de/wiki/webapi/requests/masters_clearflash)

Last update: **2020/04/19 15:28**

