

Web API request

Masters/SetSpeed

Sets the speed of a speed master from the menu.

API	https://api.avolites.com/12.0/Masters.SetSpeed.html
namespace	Masters
usage	<code>http://[ip]:4430/titan/script/2/Masters/SetSpeed?handle={handle}&value={float}</code>
example	http://localhost:4430/titan/script/2/Masters/SetSpeed?handle_titanId=1612&value=100 (link opens in new tab)
action	set BPM Master 1 to 100 BPM
parameter	Handle: the master to be set value (Float: the numeric speed value to set (see remarks)
returns	nothing if successful error messages if the request failed
remarks	Using a usernumber will fail as masters don't have one. Either assign the master to a handle and use its location or use the reserved Titan ID, see titanId in the Macros section For BPM masters the value directly transfers to a BPM value. For rate masters, unlike Masters/SetMaster which uses a normalized value (1 == 100%), here the numeric value is directly interpreted value. <code>value=10</code> sets a rate master to 10%.

Used In

- [MIDI To Web](#)
- [Web-API requests](#)

From:
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
https://www.avosupport.de/wiki/webapi/requests/masters_setspeed

Last update: **2020/04/19 15:32**

