

Modules

As stated in the [Introduction](#) modules are the smallest parts used in the Ai node-based engine. They are provided by the Ai system. A full list of the available modules is published in the manual which is installed with the software in `Distrib\Help\Ai_Man_v8.chm` and in the V9 User Manual available at the [Avolites Download site](#).

The modules used in the examples in this wiki are explained here as well so that you can easily link between modules and their use in real-life patches.

Currently these modules are discussed in this wiki:

3

- [3D Morph Model](#)

A

- [AiMediaTileTrigger](#)
- [ArtNet Input Large](#)
- [Artnet Input Small](#)
- [ArtNet Server](#)
- [Auto Select](#)

B

- [BlendMode](#)

C

- [Camera \(Controller\)](#)
- [Camera \(GL\)](#)
- [Clear](#)
- [Const Diff](#)
- [Constant](#)
- [ConstantWithText](#)
- [Convert To String](#)
- [CSV File Reader](#)

E

- [Ethernet Command](#)

F

- [Filename As String](#)
- [Formula](#)

J

- [Javascript](#)

L

- [Latch](#)
- [Light](#)

M

- [Monitor](#)

N

- [Notepad](#)
- [Null Render](#)

P

- [Patch IO](#)

R

- [Rectangle](#)
- [Render Merge](#)
- [Render To Texture](#)

S

- [Scale](#)
- [String Combine](#)

S cont.

- [String Length](#)
- [String Texture](#)
- [String To Number](#)
- [Sub String](#)

T

- [TCP Client Module](#)
- [TexScale](#)
- [Text \(Generator\)](#)
- [TexTranslate](#)
- [Texture](#)
- [Translate](#)

V

- [Vector](#)
- [Vector Join](#)
- [Vector Math](#)

W

- [Window](#)

From:

<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:

<https://avosupport.de/wiki/ai/modules>

Last update: **2018/10/15 06:01**

