Ai Modules

ArtNet Input Large

section	Network
short description	allows to recive up to 48 channels Artnet
licence level	Anjuna
ports	Server Input [multipurpose] - connect to an Artnet device in order to receive data
	ArtNet Lock [control/numeric] - whether to lock to Artnet
	Universe Input [control/numeric] - set the Artnet universe externally
	Base Channel Input [control/numeric] - set the Base Channel externally
	Channel Offset Input 0~39 [control/numeric] - set the channel offset per channel externally
	Output 0~39 [control/numeric] - output the received data, either 0...1 (`8-Bit` off) or 0...255 (`8-Bit` on)
parameter	param 1 [type] - description
skins	./.

used in example

- Visualiser: Moving Matrix
- Visualiser: Moving RGB Matrix
- Moving Screens

Manual

> text from manual
> picture_from_manual

From:
https://avosupport.de/wiki/ - **AVOSUPPORT**

Permanent link:
https://avosupport.de/wiki/ai/modules/network/artnetinputlarge?rev=1540137921

Last update: **2018/10/21 16:05**