

Titan Property

Editor.Shapes.Spread

API	http://api.avolites.com/11.0/Editor.Shapes.Spread.html
description	Gets or sets the spread for all shapes being edited. Updates the value in the Titan engine.
Namespaces	Editor.Shapes
type	Int32

example

```
<step>ActionScript.SetProperty.Integer('Editor.Shapes.Spread',1)</step>
```

Sets the shape spread to 1.

used in

- [Shapes - Reverse, Offset, Restart](#)
- [Set Playback's Shape Spread](#)

From:

<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:

<https://avosupport.de/wiki/macros/property/editor.shapes.spread?rev=1556958775>

Last update: **2019/05/04 08:32**

