

Web API request

# Masters/Flash

Flashes the master to full.

<b>API</b>	<a href="https://api.avolites.com/12.0/Masters.Flash.html">https://api.avolites.com/12.0/Masters.Flash.html</a>
<b>namespace</b>	Masters
<b>usage</b>	<code>http://[ip]:4430/titan/script/2/Masters/Flash?handle={handle}</code>
<b>example</b>	<code>http://localhost:4430/titan/script/2/Masters/Flash?handle_titanId=1605</code> (link opens in new tab)
<b>action</b>	temporarily sets the grand master at 100%
<b>parameter</b>	Handle - the master to be flashed
<b>returns</b>	nothing if successful error message if request failed
<b>remarks</b>	<p>Using a usernumber to identify the master will fail as masters don't have one. Either assign the master to a handle and use its location or use the reserved Titan ID, see <a href="#">titanId</a></p> <p>the flashed master must be 'unflashed' from the Web API using <a href="#">Masters/ClearFlash</a> - in order to unflash it on the console do Release Release All Masters, bring the fader up to 100% to level-match, and then lower the fader.</p> <p>flashing a rate or BPM master results in sending it to the maximum of its range as set in playback options.</p>

## Used In

- [MIDI To Web](#)
- [Web-API requests](#)

From:

<https://www.avosupport.de/wiki/> - **AVOSUPPORT**



Permanent link:

[https://www.avosupport.de/wiki/webapi/requests/masters\\_flash](https://www.avosupport.de/wiki/webapi/requests/masters_flash)

Last update: **2020/04/19 15:31**